

Cable **GATOR**®

Instructions for Use



You have just purchased a quality Cable Prep® Brand product. Follow this two-step procedure for beveling the center conductor and removing any residual dielectric from it. The Gator® will make your final prep a snap!

1. Insert the center conductor into the beveller part of the tool and **with light pressure** rotate the tool back and forth three to five times. Rotate tool 180° and repeat back and forth motion three to five times. YOU ARE NOT TRYING TO SHARPEN THE CENTER CONDUCTOR, you are removing any outer burrs, which if left on the center conductor may cause damage to the seizing mechanism of the connector.
2. Remove the bonded dielectric with the Gator® "Teeth". Grasp the center conductor with the teeth of the Gator® tool. Rotate tool side to side to cut through foam dielectric. Using short strokes and rotating the tool side to side, continue until dielectric builds up behind the teeth. Keep rotating the tool side to side while pulling the tool in a downward motion until all dielectric is removed.

Your cable is now prepped and ready for the connector. **Please note:** When Gator® teeth appear worn, use a Phillips head screwdriver to remove the teeth and flip the teeth so that the other side may be used. For replacement teeth for the Gator® tool, simply ask your Cable Prep® distributor for part number "Teeth".

As with any rotating equipment, eye protection must be worn at all times.

CablePrep®
Tools You Trust Since 1979