

TONEcube – Tone Generator

- Trace wire paths and identify cables in common wiring systems.
- Five discrete tracing tones.
- Constant output level over useful battery life.
- Heavy-duty leads with rugged dual-mode modular plug for direct connection to both RJ11 & RJ45 jacks.
- Momentary slide switches prevent accidental operation.
- Designed for use with Klein Tools VDV test tools (Cat. No. VDV526-054, VDV501-060).
- Works with many other manufacturers' analog tone probes.



Cat. No.	Batteries	Battery Life	Height	Width	Depth	Weight (oz.)
VDV500-051	9V	120 hours active 4 years standby	2.7" (70 mm)	2.5" (63 mm)	1.42" (36 mm)	3.4 (96 g) with out battery 5.0 (142 g) with battery

Features

VDV500-051

	Tones	5, high-warble, low-warble, mono, ascending, descending
	Heavy-Duty Leads	
	Rugged RJ11/RJ45 Modular Plug	
	Continuity Testing	
	Voltage Overload Protection	
	Line Status & Polarity	
	Power-On Flashing LED Indicator	
	Auto Power-Off	
	Low Battery Indicator	
	Lanyard Attachment Loop	



VDV500-051

PROBEplus – Tone Tracing Probe

- Trace wire paths and identify cables in common wiring systems.
- Amplifier overload LED improves accuracy, warning against misreads.
- Dual mode power button with Power-On LED indicator – tap or hold.
- Recessed buttons prevent accidental operation.
- Designed for use with Klein Tools VDV test tools (Cat. No. VDV500-051, VDV526-054, VDV526-052, VDV501-053, VDV501-809).
- Works with many other manufacturers' analog tone generators.
- Replacement tips available (Cat. No. VDV999-065).



VDV500-060



Cat. No.	Batteries	Battery Life	Height	Width	Depth	Weight (oz.) with out battery
VDV500-060	9V	25 hours active 4 years standby	9.9" (252 mm)	2.0" (50 mm)	1.14" (29 mm)	4.4 (112 g) 6.0 (152 g)

Features

VDV500-060

	Amplifier Overload Indication	
	Adjustable digital volume control	
	Tap-Mode Operation	
	Hold-Mode Operation	
	Power-On LED Indicator	
	Visual Notification	
	Auto Power-Off	
	Low Battery Indicator	
	Replaceable Tip	
	Lanyard Attachment Loop	

All dimensions are in inches and (millimeters).

▲WARNING: Always wear approved eye protection.

▲WARNING: Do NOT use on energized circuits.